

INSTALLATION & SIGHT-IN INSTRUCTIONS FOR 4-PIN SCOPES ON TETRA SERIES ADJUSTABLE BOW SIGHTS

In recent years, the concept of incorporating a fixed, multi-pin scope onto a sliding sight base has gained in popularity. While there are multiple ways to use this combination, the most-used method is described in a step-by-step process below.

Use of the **TOP PIN** as your fixed “20” and “20-100” slider:

- Step 1. See Steps 1-4 on the main instruction sheet.
- Step 2. Depending on what model TETRA you have, either rotate the DIAL or move the ARM to position the SLIDE in the UPWARD-MOST position. Tighten the DIAL LOCK or ARM LOCK.
- Step 3. Using the **TOP PIN**, sight in at 20 YARDS by loosening the (2) screws 1/4 turn in the INFINITE ADJUST PLATE, and sliding it vertically along the SLIDE scale.
- Step 4. If you are shooting a TETRA or TETRA MAX, the indicator needle will be aligned with the “0” on the SET-UP tape. If you are shooting a TETRA LT, apply one of the enclosed 0-65 SET-UP tapes, centering it on the sight fan, and with the “0” positioned IN LINE with the needle.
- Step 5. Using the **TOP PIN**, sight in at 60 yards by adjusting the TAPE DIAL or ARM.
- Step 6. Once you are accurately sighted in at 60 yards, tighten the DIAL LOCK or ARM LOCK KNOB. Mark and make note of the number (example: number 35) that is nearest to the needle.
- Step 7. Locate the desired tape in the enclosed kit (our example shows that we need tape #35). If you have a TETRA or a TETRA LT, simply peel tape 35 from the kit and apply it to the TAPE DIAL (sight fan on TETRA LT), ALIGNING THE “60” YARD MARK WITH THE NEEDLE. Apply the enclosed MYLAR to secure the tape.

If you are shooting a TETRA MAX, apply desired tape to the BLANK YARDAGE WHEEL. Use the enclosed MYLAR tape to connect both ends of the YARDAGE TAPE. Loosen and remove the SET-UP WHEEL and replace it with the YARDAGE WHEEL, aligning the “60” under the needle or magnifier. Tighten the set screw. Do **NOT** over-tighten.
- Step 8. Move the SLIDE back to the UPWARD-MOST POSITION, placing the 20 YARD mark under the needle. Use the DIAL LOCK or ARM LOCK to lock the SLIDE in place.
- Step 9. Your Tetra Series sight is now sighted in from 20-100 yards using the TOP PIN and the YARDAGE TAPE. The extra pins may now be individually adjusted in the PIN CARRIER and set for additional yardage settings (example: 30 yds, 40 yds, 50 yds).

FOR MORE IN-DEPTH INSTRUCTIONS, VISIT OUR WEBSITE AT

https://www.hhasports.com/download_category/instructions/